

LIPSTICK PEPPER SPRAY



POWERFUL PEPPER SPRAY

Sprays up to 15 feet with 2 million Scoville heat units of law enforcement-strength stopping power.



MULTIPLE DISCREET CARRY OPTIONS

Lipstick-like design allows you to store pepper spray in your purse, cosmetics bag or pocket to help avoid detection by others.

OTHER RUGER PEPPER SPRAY PRODUCTS:

- Ultra Pepper Spray System
- Key Chain Pepper Spray
- Bear Repellent
- Restraint
- Pro Extreme Speed Release Pepper Spray
- Stealth Pepper Spray System
- Armor Case Pepper Spray
- Lockdown

LIPSTICK PEPPER SPRAY

Active Ingredient: 10% Oleoresin Capsicum. Strong inflammatory and irritant affects the mucous membranes (eyes, nose, throat) and skin. May cause eyes to close and difficulty breathing. Effects may last up to 45 minutes.

Restriction: Not to be sold to minors or where prohibited by law. Use of this product for other than self defense is a crime that may subject you to punishment under applicable law. Do not carry on any passenger aircraft.

Distributed by: Tornado Personal Defense Systems, Inc.
1465 Slater Road, Ferndale, WA 98248 | 877-460-0939



WWW.RUGER.COM/TORNADO

RLS092



RUGER®

LIPSTICK PEPPER SPRAY HAVE A PLAN AND ALWAYS BE PREPARED!

LIPSTICK

Features:



Spray



Multiple Carry Options

Available in:

Pink Blue
Silver Red
Black



® Powered by Tornado®



RUGER®

LIPSTICK PEPPER SPRAY


WARNING: READ INSTRUCTIONS CAREFULLY PRIOR TO USE.

Notice: Possession and/or use of pepper spray may be prohibited or regulated in some states or locales. Improper use may result in criminal action, including but not limited to lawsuits, fines, prosecution and even imprisonment. Pepper spray should only be used in cases where you (or someone you are protecting) are in an unavoidable and threatening situation.

Exposure: KEEP OUT OF REACH OF CHILDREN. Severe irritant affects eyes, skin and respiratory areas. In case of exposure, rinse eyes with water. Wash skin thoroughly with soap and water. DO NOT RUB. Do not apply creams, salves or lotions. If symptoms persist after 45 minutes, call a physician.

Caution: Contents under pressure. Keep away from heat. Do not store above 120° F, below 32° F or in direct sunlight. Use caution when activating in windy conditions. Do not puncture or incinerate can. Do not carry on any passenger aircraft.

1. Thumb Trigger 2. Spray Nozzle 3. Pepper Spray



Disclaimer of Warranties: To the extent permitted by law, Ruger® and Tornado® shall not be liable for damage, injury, loss, direct or consequential including death arising out of the use of, or inability to use this product. No warranty is expressed or implied. Responsibility for safe and lawful use rests solely with the user.

The Ruger Ultra Pepper Spray System features the same capabilities of the Lipstick Spray, plus:



125 Decibel Alarm Screams for attention even if you can't.



Speed Release All features activate in less than one second.



Bright Strobe Light Confuses attackers and gives you a chance to get away.



Free Belt Clip

Check Out These Great Ultra Pepper Spray Accessories:



ARMBAND



VEHICLE DEFENSE



HOME DEFENSE



REPLACEMENT HEAD

- 1. WARNING** When practicing do not press the Thumb Trigger.

Before placing your Lipstick Pepper Spray in your bag, familiarize yourself with the device.

- 2.** Your Pepper Spray will shoot from the Spray Nozzle at a slightly upward angle. A sweeping motion is most effective in ensuring you hit your target.

Point the Lipstick Pepper Spray head at the aggressor and press down firmly with your thumb on the Thumb Trigger to release the Pepper Spray. (Do not press trigger while familiarizing yourself with the product).

- 3.** Now that you are familiar with the operation of your Lipstick Pepper Spray, place the cap on securely and store the device in your bag.

Please ensure that you are familiar with the operation of your Lipstick Pepper Spray, and that you are aware of the applicable laws in your area with respect to the use of this type of product.

WWW.RUGER.COM/TORNADO